

WALLPAPER

SURFACE REQUIREMENTS



MADE YOU LOOK



Newly plastered walls

- The surface of the walls has to be smooth, flat and latex/paint prepared. Class A plastered.
- The wallpaper takes on the structure of the wall.
- Installation of the wallpaper is not possible if the wall has not been prepared with a primer.

Please note: The primer must not be done with paint or latex.

Existing painted walls

- The paint layer needs to have a good adhesion to the wall. No loose or chipped paint.

Plaster walls, MDF walls, Multiplex walls

- Seams and screw holes must be filled, flattened and sanded.
- The surface need to be prepared with a primer, for example Sigmaxfix Universal or Flevopol 1:1, (diluted) Latex is not suitable as a primer!
- Installation of the wallpaper is not possible if the wall has not been prepared with a primer.

Painted or bending MDF

- Seams and screw holes must be filled, flattened and sanded for a perfect result.
- The surface must be prepared with a two component primer (preferably from the brand Lucite).

Lacquered walls and doors

- Seams and screw holes must be filled, flattened and sanded for a perfect result.
- The surface needs to be grease-free.

Formica, HPL walls & Plastic doors

- The surface needs to be grease-free.
- Seams need to be tight-fit. The wallpaper will be cut-open on these seams.
- Otherwise, fill the seams and screw holes with two-component filler and sand to create a perfectly smooth surface for a seamless application of the wallpaper.

WELL BEGUN IS HALF DONE

WALLPAPER

SURFACE REQUIREMENTS



MADE
YOU
LOOK



WELL BEGUN
IS HALF DONE

Concrete walls

Installation at your own risk, bubbles can form because there are often air holes on the surface and formwork is waxed which can make the concrete greasy.

Please note: If concrete is plastered, it can be wallpapered (see the heading *plastered walls* for more information).

Fiberglass wallpaper

- The (new) wallpaper will take on the motif of the existing fiberglass wallpaper.
- Preferably not with (very) coarse patterns in connection with adhesion.

Paper wallpaper

No gluing possible. First the wallpaper has to be removed and then the wall has to be leveled.

Pre-treated metal surface

The surface needs to be grease-free.

Untreated metal surface

- No gluing possible.
- The surface needs to be pre-treated to prevent corrosion.

